


RCA Radiola 62

SERVICE NOTES

Prepared Especially for RCA Dealers



RCA Radiola 62

First Edition - 25M
Copyright November, 1928

Radio Corporation of America

SERVICE DIVISION OF THE PRODUCTION AND SERVICE DEPARTMENT

233 BROADWAY, NEW YORK CITY

DISTRICT SERVICE STATIONS

BROOKLYN, N. Y. CHICAGO, ILL. SAN FRANCISCO, CAL.
Bld. No. 19-168 - 39th St. 2001 West Pershing Road 274 Brannan St.
DALLAS, TEX.—Santa Fe Bldg., Unit No. 2
ATLANTA, GA.—Monroe Bonded Warehouse, Spring and Peters Sts.

OR TWO ABOUT SERVICE

hand with sales. The well-informed RCA Authorized
at time of sale in affording information as to proper
Subsequent service and repair may be required by rea-
and mishandling, to the end that RCA Loudspeaker and
entirely satisfied.

ice can best be rendered by properly equipped service
thoroughly trained personnel with a knowledge of the
RCA Loudspeakers and Radiolas.

izations have been established by the RCA Distributors,
Dealers are advised to refer any major work or replace-
Distributors. Minor replacements and mechanical and
may be undertaken by the RCA Dealer.

ing this phase of the Dealer's business the Service Divi-
prepared a series of Service Notes—of which this booklet
technical information and practical helps in servicing
Radiolas.

has been compiled from experience with RCA Dealer's
represents the best practice in dealing with them. A
Service Notes will establish their value, and it is sug-
for ready reference.

ving the Service Notes, the RCA Service Division main-
s who are qualified to render valuable help in solving
engineers call upon the trade at frequent intervals to
performance of service work.

ration of America. Confidential and to be used only by its
Dealers in furnishing service in connection with its apparatus.

Copyright 1928—Radio Corporation of America

CONTENTS

	Page
A Word or Two About Service.....	2
Introduction	5
Service Data Chart.....	36

PART I—INSTALLATION

	Page		
Antenna (Outdoor Type)	7	Knobs	9
Antenna (Indoor Type)	7	Receiving Loud Local Stations	10
Ground	9	Distortion Due to Loud Signals	10
Radiotrons	9	Pick-Up from Long Wave High Power Stations	10
Line Switch	9	Location of Radiola in Room	11
		Shipping Bracket for Reproducer Unit	11

PART II—SERVICE DATA

Antenna System Failures	11	Adjustment of R.F. Compensating Condenser..	16
Radiotron Sockets	11	Adjustment of I.F. Transformers	17
Radiotron Prongs	11	Output Condenser and Choke, Output Trans-	
Loose Volume Control	11	former and Filter Condensers	20
Adjustment for Slack Drum Control	12	Voltage Supply System	20
Broken Condenser Drive Cable	12	Voltage Readings	20
Hum	12	Checking Resistance Values	21
Distortion in Reproducer	13	Testing Disc Rectifier	21
Low Volume and Weak Signals	13	Reproducer Unit	21
Audio Howl	14	Centering Cone of Reproducer Unit	22
Distorted Reproduction	15	Radiola 62 Continuity Tests	22
Adjustment of Oscillator Trimming		Voltage Readings at Radiotron Sockets.....	27
Condensers	15		

PART III—MAKING REPLACEMENTS

Replacing the Volume Control	28	Replacing Tapped Resistance Unit in Receiver	
Replacing R.F. Transformer and Oscillator		Assembly	32
Assembly	29	Replacing Cone of Reproducer Unit	33
Replacing Radiotron Gang Sockets	29	Replacing Filter Condensers and By-Pass	
Replacing Main Tuning Condensers and Drive		Condensers	33
Cable	29	Replacing Power Transformer or Filter	
Replacing By-Pass Condensers	30	Reactor	33
Replacing the Audio Transformer	30	Replacing Terminal Strip	34
Replacing Condenser Drive Cable	31	Replacing Miscellaneous Parts in S.P.U.	34
Replacing Dial Scales	31	Replacing Coupling Unit	35
Replacing Power Cable	31	Replacing Condenser Bank of Field Supply	
Replacing Intermediate Transformers	31	Unit	35
		Replacing Rectifier Stack	35

ILLUSTRATIONS

Radiola 62	1	Schematic Circuit of Voltage Supply System	19
Rear Interior View of Radiola 62	4	Internal Connections of Filter and By-Pass	
Socket Power Unit	5	Condensers	20
Field Supply Unit	6	Internal Connections of Coupling Unit	20
Radiotron Sequence	7	Internal Connections of Condenser Bank in	
Schematic Circuit Diagram of Radiola 62	8	Field Supply Unit	20
Long Wave Interference Filter	10	Centering Cone	21
Dimensions of Non-Metallic Screw Driver	12	Location of Radiotron Sockets and Other	
Adjusting Trimming and Compensating Con-		Parts	22
densers	13	S.P.U. Continuity Wiring	23
180 K.C. Test Oscillator	14	Receiver Continuity Wiring	24
Location of Neutralizing, Trimming, Tuning		Field Supply Continuity Wiring	26
and Compensating Condensers	16	Receiver Sub-Chassis Assembly	28
Adjusting Neutralizing Condensers	17	Removing Receiver from Cabinet	30
Internal Connections of I.F. Transformers	18	Removing Field Supply Unit from Cabinet ...	34
Cable Connections to S.P.U. and Field Supply			
Terminal Strips	18		

RCA RADIOLA 62




Figure 1--Rear interior view of Radiola 62, showing Receiver Chassis at top, Reproducer below shelf and S.P.U. at bottom left and Field Supply Unit at bottom right

RCA RADIOLA 62

(105-125 Volts. 50-60 Cycle A. C.)

SERVICE NOTES

Prepared by RCA Service Division

INTRODUCTION

RCA Radiola 62 is an eight-tube socket powered radio receiver employing seven UY-227 Radiotrons and one UX-171A Radiotron. One Radiotron UX-280 is used in a socket power unit for supplying all grid and plate voltages. A dry disc type rectifier furnishes direct current of the correct voltage to the field of the reproducer unit. Radiola 62 is fundamentally a console cabinet model of Radiola 60, utilizing a new type dynamic reproducer and having such circuit changes as are necessary for use with a speaker of this type. Figure 1 illustrates a rear view showing the principal parts. Figure 2 illustrates the socket power unit and Figure 3 shows the field supply unit.




Figure 2—Socket power unit

Radiola 62 is designed to operate on alternating current of 105 to 125 volts, 50 to 60 cycles, such as is used for house lighting. Connection to D. C. lines or to A. C. lines of different rating may damage the Radiola or the Radiotrons.

Radiola 62 is also made in models designed for 105-125 volts, 25-40 cycles A. C. operation. In this model the power transformer is different from that used in the 50-60 cycle models and the condenser shunted across the output of the disc rectifier has a capacity of 6 mfd. instead of 4 mfd., as used in the 50-60 cycle sets. All other parts are identical in both models and the Service Notes apply to each equally well.

The following circuit characteristics are incorporated in Radiola 62.

- (a) As already stated, Radiola 62 uses seven Radiotrons UY-227 and one Radiotron UX-171A connected up in an eight-tube super-heterodyne circuit with a UX-280 in the S. P. U. for grid and plate supply.
- (b) A new type dynamic reproducer unit is used, the field current for this unit being obtained from a dry disc type of rectifier, thus keeping the load on the Radiotron UX-280 at a minimum value.
- (c) The circuit consists of one untuned coupling stage, one tuned R.F. stage, a tuned heterodyne detector, two intermediate R.F. stages, an oscillator, a second detector and a power amplifier.




Figure 3—Field supply unit

- (d) The second detector, operated at 160 volts plate potential with grid bias, changes the radio frequency current of the intermediate stages into audio frequency current. This gives sufficient output to operate the power tube directly from the second detector, thus eliminating any distortion that might be present if an intermediate audio stage were used.
- (e) The volume control regulates the grid bias on all radio and intermediate frequency amplifying stages, giving a positive control of volume, even on nearby local stations, without distortion.

Figure 4 illustrates the sequence of the Radiotrons in the receiver, omitting Radiotron UX-280 in the socket power unit. From right to left, when facing the front of the Radiola, the Radiotron sequence is as follows:

Radiotron No. 1 is an untuned stage of radio frequency amplification. It is coupled directly to the antenna and ground across a 2000-ohm resistance and functions as a coupling tube to the antenna system.

Radiotron No. 2 is a stage of tuned radio frequency amplification. It is tuned by means of the first of the gang condensers.

Radiotron No. 3 is the tuned heterodyne detector. It is tuned by the center of the gang condensers.

Radiotrons No. 4 and No. 5 are the first and second intermediate frequency stages. These stages are tuned to a frequency of 180 K.C., giving ample distance between the two peaks of the oscillator to eliminate any possibility of stations coming in at more than one point on the tuning dial.

Radiotron No. 6 is the oscillator. It is tuned by the third of the gang condensers. Two trimming condensers are provided at the rear of the receiver assembly for adjusting the oscillator circuit to keep the beat note at the correct frequency for the intermediate stages.

Radiotron No. 7 is the second detector. It operates at a plate potential of 160 volts with the proper grid bias and does not use a grid leak or condenser. Its output is sufficient to drive the power amplifier.

Radiotron No. 8 is the power amplifier. A choke and condenser arrangement couples this tube to the step-down transformer that matches the impedance of this output circuit to that of the cone coil of the reproducer unit. This arrangement gives a quality of reproduction not obtainable with the use of an output transformer alone.




Figure 4—Radiotron sequence

These various principles incorporated in Radiola 62 and illustrated in the schematic circuit Figure 5, provides a radio receiver of advanced design, excellent performance and good tone quality.

PART I—INSTALLATION

[1] ANTENNA (Outdoor Type)

Due to the high sensitivity of Radiola 62 the antenna length need only be approximately 25 feet. It should be erected as high as possible and be removed from all obstructions. The lead-in should be a continuation of the antenna itself, thus avoiding all splices which might introduce additional resistance and, in time, corrode sufficiently to seriously affect reception. If it is absolutely necessary to splice the lead-in to the antenna the joint must be carefully soldered to insure a good electrical contact. Clean off all excess flux and tape the connection, to protect it from the oxidation effects of the atmosphere.

High-grade glass or porcelain insulator supports are required, and at no point should the antenna or lead-in wire come in contact with any part of the building. Bring the lead-in wire from the outside through a porcelain tube insulator to the inside of the house for connection to the receiver.

The antenna should not cross either over or under any electric light, traction, or power line and should be at right angles to these lines and other antennas. An outdoor antenna should be protected by means of an approved lightning arrester, in accordance with the requirements of the National Fire Underwriters' Code.




Figure 5—Schematic circuit diagram of Radiola 62

[2] ANTENNA (Indoor Type)

Where the installation of an outdoor antenna is not practical, satisfactory results may generally be obtained by using an indoor antenna of about 25 feet of insulated wire strung around the picture moulding or placed under a rug. In buildings where metal lathing is employed, satisfactory results are not always possible with this type of antenna. However, due to its sensitivity, Radiola 62 will generally give entirely satisfactory reception with an indoor antenna.

[3] GROUND

A good ground is quite as important as a good antenna. No specific recommendations can be given in this matter as conditions vary in different locations. Water and steam pipes usually make good grounds. Gas pipes usually make poor grounds and, as a rule, are to be avoided. If neither water nor steam pipes are available, a pipe or metal rod may be driven into the ground to a depth of several feet. The success of this type of ground depends upon the moisture present in the soil. The ground lead should be connected by means of an approved ground clamp to a section of pipe that has been scraped and thoroughly cleaned. The connection should be inspected from time to time to make certain that a clean and tight electrical contact exists between the clamp and pipe. The service man should experiment with various grounds, and employ the one giving the best results.

A spark will occur if the power supply is "on" when making the ground connection. This action is normal, being caused by the discharge of one of the .1 mfd. condensers connected across the power input to the disc rectifier. No current is consumed as no load is being drawn through the condenser.

[4] RADIOTRONS

A guide shield is provided on all the receiver Radiotron sockets to facilitate the insertion of the Radiotrons. The seven Radiotrons UY-227 are inserted in the five-contact sockets. The Radiotron UX-171A is placed in the four-contact socket in the receiver assembly, and the Radiotron UX-280 is placed in the socket power unit.

In placing Radiola 62 into operation, if no signals are heard when tuning to a station known to be broadcasting, examine the Radiotrons. Possibly one Radiotron has been damaged in transit. Interchanging with one or more of the same type known to be in operating condition will isolate the damaged one.

Socket No. 2 (Figure 4), the tuned R.F. stage, is the most critical for selection of the Radiotrons. Place in this socket the tube which gives the loudest signal and does not go into oscillation throughout the tuning range. If no tube is found that will not oscillate, a slight re-adjustment of the R.F. compensating condenser may be necessary, as described in Part II, Section 13.

Other stages somewhat critical are the oscillator and second detector, sockets No. 6 and No. 7, respectively. The remaining tubes should be interchanged until a tube is found for the oscillator that gives the loudest signal on a given station. The second detector Radiotron should be selected for its ability to handle large volume. Select the tube for this socket that will permit the volume control to be advanced and give the greatest output without overloading.

[5] LINE SWITCH

A two-way switch is provided in the S.P.U. for adjustment to line voltages. A shield over the terminal strip holds this switch in the 120-volt position. Unless it is definitely known that the line is always below 115 volts the switch should be left in its original position. It is a good plan to leave this switch at the 120-volt position on all lines unless unsatisfactory operation is experienced. If the switch is set at the 110-volt position on supply lines exceeding 115 volts the Radiotrons in the receiver will be damaged.

[6] KNOBS

Radiola 62 uses an improved type of push knob on the station selector and volume control shafts. This knob is removed by simply pulling it off the shaft, and replaced by pushing it on. Very little trouble should be experienced, as no setscrews or other parts that might give trouble are used.

When placing this knob on its shaft care must be exercised not to push it tight against the washer between the knob and cabinet, as then it will bind. Sometimes in handling new sets the knob will have become pushed against the washer and bind. The remedy is merely to pull the knob out until it does not bind.

[7] RECEIVING LOUD LOCAL STATIONS

If excess volume control adjustment is used on local stations the signal will apparently have two peaks on the tuning dial. A further advance of the volume control will decrease the volume rather than increase it. This is entirely normal, and is caused by tube overloading. The correct method of tuning Radiola 62 on local stations is to reduce the volume control to the position where the station will be received at only one position on the station selector dial, and then adjust the volume control for the desired volume.

On some stations when tuned in with excessive volume a howl may be experienced. The remedy is to reduce the volume control until the howl disappears.

This tuning procedure should be explained to the Radiola owner when an installation is made.




Figure 6—Long wave interference filter

[8] DISTORTION DUE TO LOUD SIGNALS

In some localities extremely close to powerful broadcasting stations, reproduction may be distorted when reducing volume to a point satisfactory to the listener. When installing a set, determine by a listening test whether this condition exists or not and apply the following remedy if the reproduction is distorted.

Procure a single-pole single-throw switch (any type will do) and connect it in series with the antenna lead of the receiver. The switch may be located either inside or outside the cabinet in any convenient position. Opening the switch will disconnect the antenna and allow satisfactory reception on signals that would otherwise be distorted. The switch should be closed for reception from other stations.

[9] PICK-UP FROM LONG WAVE HIGH POWER CODE STATIONS

Should Radiola 62 be installed very close to long wave, powerful code stations, it is possible that a certain amount of pick-up and interference from them will be experienced. Trouble of this kind may be eliminated in the following manner:

- (a) Procure the following equipment:
Two Radiola 16 antenna coils (RCA Stock No. 5658).
One .0002 Mfd. fixed condenser.
- (b) Connect as shown in Figure 6.
- (c) This apparatus may be placed inside of the cabinet of the receiver or made up in a separate unit and placed in any convenient location. It acts as a filter, allowing frequencies of the broadcast band only to reach the receiver.

[10] LOCATION OF RADIOLA IN ROOM

As with other musical instruments, the location of Radiola 62 in the room should be chosen with care. Various positions should be tried until the most desirable reproduction is obtained. If this position is outside the radius of the connection cord to the A.C. outlet, an extension cord can be used.

[11] SHIPPING BRACKET FOR REPRODUCER UNIT

Radiola 62 is shipped with a metal yoke and wooden support to hold the reproducer unit in place during shipment. This wooden block and the metal yoke holding it should be removed when placing Radiola 62 into operation as it may resonate at audible frequencies and affect the reproducing qualities of the Radiola. The front flange of the reproducer offers ample support for the reproducer unit on all occasions except when shipping.

PART II—SERVICE DATA

[1] ANTENNA SYSTEM FAILURES

A grating noise may be caused by a poor lead-in connection to the antenna; or the antenna touching some metallic surface, such as the edge of a tin roof, drain pipe, etc. By disconnecting the antenna and ground leads the service man can soon determine whether the cause of complaint is within or external to the receiver and plan his service work accordingly.

[2] RADIOTRON SOCKETS

The sockets used in Radiola 62 are a six-gang UY socket assembly, a single UY socket, and two single UX sockets. One of the UX sockets is used in the socket power unit and is of a different design than that used in the receiver assembly.

The bakelite Radiotron guide shields used in the receiver assembly will prevent any possible shock from contact with high voltages in the socket when inserting the Radiotrons. The prongs of the tubes fit into this shield opening very snugly and require only a twist until the prongs find the correct holes into which they fit. This is especially helpful when inserting the five-prong tubes into their sockets.

[3] RADIOTRON PRONGS

Dirty Radiotron prongs may cause noisy operation or change the resistance of the filament circuits sufficiently to cause a hum in the loudspeaker. They should therefore be cleaned with fine sandpaper periodically to insure good contact. The use of emery cloth or steel wool is not recommended. Before re-inserting the Radiotrons in their sockets wipe the prongs and base carefully to make certain that all particles of sand are removed.

If a Radiotron will not fit into a socket without considerable pressure, look for excessive solder on one or more of the prongs. Excessive solder on the prongs may be removed with a file or knife.

[4] LOOSE VOLUME CONTROL

A loose volume control arm may cause noisy or intermittent operation. It should be bent slightly so that it makes firm contact against the resistance strip. To do this it is necessary to remove the chassis from the cabinet as described in Part III, Section 1. The volume control is then accessible. It can be released by removing the two screws that hold it to the metal frame.

[5] ADJUSTMENT FOR SLACK DRUM CONTROL

The main tuning condensers are controlled by a cable and drum arrangement giving a smoothly acting vernier movement that has no back lash.

After considerable wear or extreme changes of temperature the cable may become slack. To take up this slack open lid of cabinet and turn the cable adjusting screw with clamp until the cable is taut. This screw may become seated after several adjustments are made, thus allowing no further tightening of the cable. When this condition occurs it will be necessary to slip the cable a half turn on the grooved drum. To make this adjustment it is necessary to remove the chassis from the cabinet as described in Part III, Section 1. Remove the cable adjusting screw and clamp. The cable will then have approximately one inch slack. By removing the tapered pin holding the front grooved drum to its shaft and replacing it on the opposite side (180 degrees) the one inch slack in the cable can be taken up by using the new position of the pin for anchoring the cable. It will be noted that the tapered pin in the new position cannot be inserted as far as originally. However, it can be inserted far enough to lock the grooved drum to the control shaft and clear the metal housing. If the cable again is stretched to the maximum adjustment of the cable adjusting screw the tapered pin can be returned to its original position and an additional half turn slipped on the drum which will provide for taking up all slack. A sufficient number of grooves are provided on the drum for this purpose.




Figure 7— Dimensions of the non-metallic screw driver

[6] BROKEN CONDENSER DRIVE CABLE

A broken condenser drive cable can be replaced in the manner described in Part III, Section 7. However, if a new cable is not immediately available a temporary repair can be made in the following manner, provided the break in the cable is not in that section that passes over the small grooved drums.

Splice and solder the two ends together. Splicing consists of interweaving the strands, as with rope, and not just twisting the cable ends together as in an electrical wiring splice. Splicing gives greater strength and forms a smaller body on the cable. When soldering use plenty of flux and a small amount of solder. Heat sufficiently so that the solder adheres to all the strands of the cable. Placing the splice in an alcohol or bunsen flame affords sufficient heat and allows excess solder to drip away. This is but a temporary repair to be used only until a new cable can be procured.

[7] HUM

If a pronounced hum develops during operation check the following:

- (a) Low emission Radiotron UX-280. A low emission rectifying tube will cause excessive hum and unsatisfactory operation.
- (b) Defective center tapped resistance. A short or open of either of these resistances will cause a loud hum and imperfect operation of the Radiola.
- (c) Any open of the several grounding connections in the Radiola or voltage supply resistances may cause a certain amount of hum. These defects will have a pronounced effect on the general operation of the Radiola which will be more noticeable than the additional hum. Check by means of the continuity test given in Part II, Section 22.
- (d) Use of Radiotron UX-171 instead of Radiotron UX-171A may cause an increase of hum. It is recommended that only Radiotron UX-171A be used as a power amplifier in Radiola 62.
- (e) Defective disc rectifier or condenser across output of rectifier may cause excessive hum and faulty operation. A check of this condition can be made as described in Part II, Section 19.

- (f) Antenna and ground leads reversed. Reversing these leads opens the condenser center ground connection in the field supply unit and causes hum.

A mechanical hum caused by vibration of loose laminations in the power transformer may be corrected by removing the power transformer from the S.P.U. as described in Part III, Section 14, and heating it in a slow oven. The open end should be kept up and the compound heated sufficiently to allow it to adhere to the laminations of the transformer. After heating, the transformer should be allowed to cool for at least 24 hours and then returned to the S.P.U.

[8] DISTORTION IN REPRODUCER UNIT

Distortion in the reproducer unit may be due to any of the following causes:

- (a) Cone out of alignment. Refer to Part II, Section 21.
- (b) Leads from cone coil broken away from side of cone. Make these leads fast with a little shellac.
- (c) Loose grille, escutcheons or baffle board. Any loose part in the cabinet will cause a rattle. Tighten all loose parts.




Figure 8—Method of adjusting trimming and compensating condensers

[9] LOW VOLUME AND WEAK SIGNALS

Low volume or weak signals may be caused by:

- (a) Defective antenna system. A poor antenna and ground or one in a shielded locality may cause weak signals. The suggestions given in Part I, Sections 1, 2 and 3, should be followed if trouble of this kind is experienced.
- (b) Defective Radiotrons. A defective Radiotron in any stage may cause weak signals. Before checking other causes it is a good plan to check all Radiotrons by interchanging them with ones of a similar type known to be in good operating condition.
- (c) R.F. compensating condenser out of adjustment. If this condenser is badly out of adjustment it will have the effect of making the Radiola very insensitive. To adjust correctly refer to Part II, Section 13.
- (d) Oscillator trimming condensers out of adjustment. Should the oscillator trimming condensers be out of adjustment the Radiola may be sensitive at certain portions of the tuning scale and very insensitive at other sections. Should these condensers be badly out of adjustment, only very loud local stations will be heard. The correct method for adjustment of these condensers is given in Part II, Section 12.
- (e) Intermediate transformers not correctly tuned or matched. Should the tuning condensers connected across the secondaries of the intermediate transformers be out of adjustment, weak signals and poor tuning or, in some cases, no signals will result. Refer to Part II, Section 14, for the correct method of adjusting the I.F. transformers.

- (f) Defective A.F. transformer or output condenser and choke. A defect in any of these parts will cause weak signals and abnormal operation. Check by means of the continuity test and make any replacement that is necessary.
- (g) Low voltage from S.P.U. Check S.P.U. voltages at terminal strip with readings given in Part II, Section 17. Low voltages may be caused by a low emission rectifying tube or defective resistances in the S.P.U. or receiver. Check by means of continuity test.
- (h) Open or short of various connections in receiver. Check by means of continuity tests and make any repair or replacement that is necessary.




Figure 9—180 K.C. Test Oscillator

[10] AUDIO HOWL

Audio howl may be caused by:

- (a) Incorrect adjustment of R.F. compensating condenser. A compensating condenser adjusted to the verge of oscillation may cause a howl on nearby stations. Adjust as suggested in Part II, Section 13.
- (b) Open A.F. condenser connections. An open of the A.F. by-pass condenser may cause a howl.
- (c) Open large by-pass condenser connections. An open of the connections to the large by-pass condensers may cause a howl.
- (d) Defective volume control resistance. Should there be an open or short in the volume control or in its adjacent resistances an audio howl may develop.

- (e) Vibrating elements in receiver Radiotrons. A gradually developed howl may be due to the loudspeaker causing the receiver Radiotron elements to vibrate. To overcome this condition, interchange the Radiotrons in the receiver, especially the second detector.
- (f) Poor ground. Install ground system as suggested in Part I, Section 3.
- (g) Poorly soldered or corroded joints. Any high resistance joint throughout the Radiola may cause a howl.
- (h) Defective resistance in S.P.U. or the receiver assembly. An open resistance unit may cause howl. Under such conditions it is advisable to turn the set "off" until the trouble is found, otherwise excessive voltage rise may cause further damage.
- (i) Neutralizing condensers in intermediate transformers out of adjustment. These condensers being out of adjustment might cause an I.F. stage to oscillate which will result in a howl when a station is tuned in, especially at loud volume. Adjust the neutralizing condensers as described in Part II, Section 14.
- (j) Open of any of the several ground leads in the Radiola. This may cause some of the circuits to go into oscillation and result in a howl when a station is tuned "in." Generally a loud hum will also be present. The several grounding leads in the Receiver Assembly and in the Socket Power Unit should be checked and any open or poorly soldered joint should be repaired.

[11] DISTORTED REPRODUCTION

Under normal conditions Radiola 62 will deliver a strong signal of excellent quality to the loudspeaker. The high sensitivity of Radiola 62 makes it undesirable to operate the set at full volume when receiving from nearby broadcasting stations. If the loudspeaker production is poor, test the output from the receiver. A pair of phones may be used for this purpose. Poor quality or distortion may be due to any of the following causes:

- (a) Defective Radiotrons. Though the Radiola may be in operating condition a defective Radiotron in any stage will cause distortion. This is especially true of the second detector, audio stage and the rectifier tube.
- (b) High or low plate and grid voltages from the Socket Power Unit or a defective resistor in the Receiver Assembly. In the Socket Power Unit distortion may be caused by a defective Radiotron UX-280 or resistance unit.
- (c) Defective A.F. transformer. Check by means of continuity test and replace if necessary.
- (d) Trimming condensers out of adjustment. Should the oscillator trimming condensers be out of adjustment the beat signal may not be exactly the frequency to which the intermediates are tuned. This will cause weak signals and distortion of those received. This condition may or may not be present throughout the tuning range of the receiver. Adjust as described in Part II, Section 12.
- (e) Receiver oscillating. Should some circuit other than the oscillator be oscillating, distortion will be experienced when tuning in a station. This will be accompanied by a whistle or squeal when the carrier wave of the station is tuned in. To remedy trouble of this kind see Part II, Section 10.
- (f) Intermediate transformers out of line or not properly matched. This will have the effect of giving distorted reproduction and reduce the sensitivity of the receiver to a marked degree. Line up the entire I.F. transformer assembly as described in Part II, Section 14.

[12] ADJUSTMENT OF OSCILLATOR TRIMMING CONDENSERS

Two trimming condensers are provided for adjusting the oscillator circuit so that the beat note will always be 180 K.C. throughout the tuning range of the receiver.

The most noticeable symptom of the oscillator trimming condensers being out of adjustment is insensitivity of the Radiola in some sections or throughout the tuning range. To check the adjustment of the trimming condensers as a possible cause of any noticeable insensitivity in the receiver proceed in the following manner:

- (a) Procure the following equipment:

A modulated oscillator giving signals at 1,400 and 600 Kilocycles. The test oscillator shown in Figure 9 is suitable for this purpose.

A long, thin, non-metallic screwdriver. Such a screwdriver is shown in Figure 7 with its dimensions.

A 0-10 milliammeter. Connect the milliammeter in series with the red lead that turns to the receiver assembly as it enters the braided cable and connecting to lug No. 2 of the S.P.U. terminal strip. This places the meter in series with the plate supply of the second detector.

- (b) With the Radiola in operation, place the oscillator in operation at 1,400 K.C. close to the antenna lead and tune the Radiola by adjusting the station selector until a deflection caused by the external oscillator is obtained in the milliammeter. Adjust volume control so that deflection is not beyond scale of meter.




Figure 10—I.F. neutralizing and tuning condensers, oscillator trimming condensers, and R.F. compensating condenser

- (c) Now adjust the oscillator trimming condenser on the right, facing rear of Radiola (Figure 8) with the long, thin, non-metallic screwdriver until a maximum deflection is obtained in the milliammeter.
- (d) Adjust oscillator for 600 K.C. Tune in the Radiola with station selector and then adjust the trimming condenser to the left for maximum deflection of the milliammeter.
- (e) Now readjust at 1,400 K.C. as indicated in (b) and (c).

With this adjustment the trimming condensers are correctly adjusted for maximum efficiency, that is, so adjusted that the beat signal will be 180 K.C. throughout the tuning range.

[13] ADJUSTMENT OF R. F. COMPENSATING CONDENSER

The radio frequency compensating condenser should not be touched unless it is definitely ascertained that no other failure exists as a possible cause of receiver insensitivity, which is the most noticeable indication of the need for adjusting the compensating condenser.

An oscillating condition of the receiver may be caused by improper adjustment of this condenser.

A step by step procedure for making proper adjustment follows:

- (a) Procure a long, thin, non-metallic screwdriver (See Figure 7).
- (b) Place Radiola in operation in usual manner and tune in a weak station, preferably at the middle or upper wavelengths. If only a loud signal is available, disconnect the antenna.

- (c) Locate the position of the compensating condenser (See Figure 8).
- (d) With the volume control at the position of maximum setting adjust the screw of the condenser until the Radiola goes into oscillation. This will cause a whistle whenever a station is tuned "in." Then turn the screw in the opposite direction until the set just goes out of oscillation and no howl is experienced when receiving loud local stations. Now tune in stations throughout the range of the receiver and note whether oscillations occur. If they do, it will be necessary to reduce the setting slightly. This is the correct adjustment for the radio frequency compensating condenser.

[14] ADJUSTMENT OF I. F. TRANSFORMERS

The three I.F. transformers used in Radiola 62 are of the air core, tuned primary and tuned secondary type. The primary condenser is of the fixed type, while the secondary is adjustable. Also in each assembly an adjustable condenser is provided for neutralizing the I.F. stage.




Figure 11—Adjusting tuning condensers in I.F. stages

Should a transformer burn out or its primary fixed condenser change in capacity it will be necessary to replace that particular transformer. The correct procedure for making such a replacement is contained in Part III, Section 10.

A simple method of locating a shorted transformer is to use a resistance bridge or the resistance measuring method described in "Radiola 32 Service Notes." The approximate transformer primary D.C. resistance is 20 ohms; secondary 100 ohms. Due to the circuit arrangement it will only be possible to get a reading of 50 ohms on the secondary as the end connection goes to the neutralizing condenser and the reading must be made at the center tap connection. This test can be made from the underside of the chassis. (See wiring continuity diagram, Figure 20.)

After replacing a defective I.F. transformer or to make adjustments, the following tuning and neutralizing procedure must be followed for correctly lining up the various circuits. This is of utmost importance, as the entire performance of Radiola 62 is based on the correct functioning of its intermediate stages.

The following equipment is needed:

1. A Test Oscillator (Driver). See Figure 9.
2. A coupling lead for coupling the output of the Driver to the grid coil of the first detector.
3. A non-metallic screwdriver.
4. A "dummy" Radiotron UY-227—a normal tube with one heater prong removed.

The RCA Service Division will advise RCA Distributors how to obtain this Driver and the above items.

Preliminary steps to be taken before adjusting the tuning, neutralizing and trimming condensers:—

- (a) Remove receiver assembly as described in Part III, Section 1.
- (b) Remove main tuning condenser assembly as described in Part III, Section 4.
- (c) Replace screw holding ground lead on under side of receiver assembly and make certain that ground lead makes good contact with the chassis frame.
- (d) Connect all lugs to the S.P.U. and field supply terminal strips. Unsolder the red lead—connected to lug No. 2—that turns to the receiver assembly as it enters the braided cable and connect it to the clip from the Driver. The other lead with the spade terminal from the Driver should also be connected to terminal No. 2 on the S.P.U. terminal strip. These connections merely place the milliammeter in the Driver test set, in series with the plate supply to the second detector.




Figure 12—Internal connections of I.F. transformers.




Figure 13—Receiver Cable connections to the S.P.U. and Field Supply terminal strips.

- (e) Now place the coupling coil from the Driver under the center coil of the R.F. and Oscillator assembly. This is the transformer between the tuned R.F. stage and the first detector. Replace all Radiotrons except the Oscillator and turn operating switch "ON."
 - (f) Place Driver in operation by switching "ON," and set switches and vernier condenser at 180 K.C. The note from the Driver will then be heard in the loudspeaker. The I.F. transformer tuning condensers may now be adjusted as follows:
 - (a) Adjust the tuning condensers successively on the third, second and first I.F. transformers (Figures 10 and 11), for maximum signal in the loudspeaker and maximum reading on the milliammeter. If pointer should go off milliammeter scale reduce the volume control. After making one adjustment on the transformers it is a good plan to repeat, as slight changes may have occurred in tuning the other circuits. No signal, or a loud howl indicates neutralizing condensers are out of adjustment and they should be readjusted.
- A maximum reading by adjusting all three tuning condensers indicates correct tuning of the intermediate stages.
- It is now necessary to check the neutralization of the I.F. stages as follows:

- (a) Leave all adjustments and apparatus in position on completion of tuning, but substitute a pair of phones for the loudspeaker by disconnecting leads to terminals 3 and 4 of the field supply unit and connect phone tips to these terminals. Place dummy Radiotron in first I.F. socket. Now adjust the neutralizing condenser on the first I.F. transformer for the position of minimum or no signal. This is easily identified and the adjustment is not critical.
- (b) Replace the first I.F. tube and place "dummy" tube in second I.F. stage and adjust the neutralizing condenser on the second I.F. transformer for position of minimum or no signal as described in the preceding paragraph (a). Figure 12 illustrates the internal connections of the I.F. transformers. It will be noted that the two condensers on the third transformer are connected in parallel for tuning. This stage does not require neutralizing.

After the I.F. transformers are properly tuned and neutralized they should perform at their maximum efficiency. It is a good plan to check the adjustments of the two oscillator trimming condensers (See Figure 20) at this point. The correct method




Figure 14—Schematic circuit diagram of the voltage supply system

for doing this is indicated in Part II, Section 12. The Driver illustrated in Figure 9 may be used for this adjustment. The procedure for adjusting the trimming condensers follows:

- (a) Replace main tuning condensers and solder all connections in place. Place coupling lead of the oscillator near the Radiola antenna lead.
- (b) Set Driver switches and vernier condenser for 1,400 K.C.
- (c) With all Radiotrons in place in the receiver tune for Driver signal with main tuning condensers. If reading goes off milliammeter scale reduce volume control.
- (d) Adjust trimming condenser on right (facing rear of Radiola, Figure 8) for a maximum reading.
- (e) Shift frequency of Driver to 600 K.C. and tune in with main tuning condensers. Adjust trimming condenser on left for maximum milliammeter reading. This is the condenser on the left of the other trimming condenser.
- (f) After adjusting at 600 K.C., check again at 1,400 K.C., and make any readjustment necessary.

This check of the trimming condensers completes the adjustments to be made in Radiola 62 with the Driver. The receiver assembly should now be returned to the cabinet (Figure 13 shows the cable connections) and the Radiola returned to normal operation.

Due to the increased sensitivity of the receiver it may be necessary to reduce the setting of the R.F. compensating condenser to prevent the tuned R.F. stage from oscillating. This can be ascertained by tuning in stations of different wavelengths and noting if the receiver oscillates at any point throughout its tuning range. (See Part II, Section 13.)

[15] OUTPUT CONDENSER AND CHOKE, OUTPUT TRANSFORMER AND FILTER CONDENSERS

The filter condensers are located in one container in the S.P.U. (See Figure 2) and their internal connections are shown in Figure 15. The output condenser and choke and output transformer comprising the coupling unit in the field supply, are located in another unit. The internal connections are shown in Figure 15A. The procedure for testing the choke or transformer windings is to "click test" for an open. To test the condensers they should be charged and then discharged by shorting their terminals with a screwdriver. A condenser that will not retain its charge is defective. Approximately 200 volts D.C. should be used when making this test.

An open output condenser or an open or shorted choke will cause weak and distorted reproduction. A defective filter condenser is indicated by excessively hot plates, possibly showing color, in Radiotron UX-280. Shorted by-pass condensers will cause abnormal operation or in-operation.

[16] VOLTAGE SUPPLY SYSTEM

Figure 14 illustrates a schematic diagram of the cathode, grid and plate voltage supply system of the various tubes used in the receiver assembly.

This receiver uses the series supply arrangement for securing different drops through various sections of a resistor placed in the plate return lead to secure proper bias for the grid circuits and proper potential for applying to the cathodes and heaters. Electrically the volume control is a section of this resistance and it functions by varying the grid bias on the R.F. and I.F. stages sufficiently to give a positive control of signal strength delivered to the second detector.




Figure 15—Internal connections of filter and by-pass condensers




Figure 15A—Internal connections of the coupling unit




Figure 16—Internal connections of condenser bank for field supply unit

A bleeder resistor of 20,000 ohms is provided across the supply circuit at the 135-volt position. The use of this resistor prevents any excessive rise in voltage that would otherwise occur upon removal of all Radiotrons or if some failure resulting in reduced load occurred in the receiver.

[17] VOLTAGE READINGS

When checking Radiola 62 for possible defects it is good practice to check the voltage of the various sources of current. To do this a service man will need both an A.C. and D.C. Voltmeter, the D.C. meter being 600 ohms per volt or higher in resistance. The following voltages at the terminal strip of the S.P.U. are correct with all tubes in place, the line adjustment switch in the correct position for that particular location and the set in operating condition. The tubes must be in good condition otherwise the D.C. voltages may be excessively high.

The shield over the terminal strip must be removed before any readings can be made. The terminal numbers are counted from front to rear of the Radiola, No. 1 being near the front and No. 11 near the rear.

<i>Terminals</i>	<i>Correct Voltage</i>
2 to 7	210 D.C.
3 to 7	160 D.C.
4 to 7	110 D.C.
8 to 9	5 A.C.
10 to 11	2.5 A.C.

[18] CHECKING RESISTANCE VALUES

When checking a Radiola 62 for possible trouble it is always a good plan to check the various resistance values of different strips used both in the receiver assembly or in the socket power unit. These values are shown in the schematic circuit diagram, Figure 5. A resistance bridge should be used for checking these values, or if this is not available, the method suggested in "RCA Radiola 32 Service Notes" (page 16) will give good results for the lower values of resistance. The high values, such as 14,300 and 20,000 ohms may be checked by measuring the voltage drop across them, after ascertaining that all other circuits are in correct operating condition.

[19] TESTING DISC RECTIFIER

The disc rectifier may be checked by measuring the output voltage that is delivered to the field of the reproducer unit. This should be 100 volts with the field connected. With the field disconnected it should rise slightly to about 140 volts.

Across the output of the rectifier is connected a 4 mfd. condenser. (See Figure 16.) Should this condenser become shorted, the fuses on the line will probably blow and the set




Figure 17—Adjusting the position of the cone

become inoperative. If the fuses do not blow immediately, the rectifier will be damaged. A shorted condenser can be located by means of a click test and it should be replaced as described in Part III, Section 18.

Precaution—The operation of the disc rectifier depends on the pressure to which the discs are held. *Do not* loosen the bolts that hold them together as it is highly improbable they can be returned to normal operation without special instruments. Should replacement become necessary, remove the bracket and unit together. The replacement part is supplied with brackets so that replacement is comparatively easy.

[20] REPRODUCER UNIT

Radiola 62 uses a new type eight-inch dynamic reproducer which makes possible excellent quality of reproduction. The field coil assembly is the same as that used in Loudspeaker 105 with the exception that the mounting bracket is not used. The flange, however, is larger and is designed so that the entire unit may be supported by it from the baffle board. The cone is an eight-inch corrugated type, giving a smooth response to all frequencies and having a treatment to make it weatherproof and free from rattle.

A check on the continuity of the cone coil or field can be made by disconnecting them from all other terminals and click testing for continuity. An open of either coil will indicate a defect which must be remedied by replacing the entire cone or the field coil.

[21] CENTERING CONE OF REPRODUCER UNIT

To properly center a new cone or one out of center use the following procedure:

- (a) Remove the grille by pulling the left side when facing the front of the Radiola.
- (b) Loosen center screw of cone, but do not remove it.
- (c) Insert three cardboard strips about the thickness of a visiting card, $1\frac{1}{2}$ " x $\frac{1}{4}$ " in size, through the center web of the cone into the space between the pole piece and the cone (Figure 17). This will give the cone coil the same clearance on all sides of the pole piece.
- (d) Tighten the center screw holding the web of the cone and remove the three strips. The cone is now properly centered. Replace the grille previously removed.

[22] RADIOLA 62 CONTINUITY TESTS

The following tests will show complete continuity for the receiver assembly, socket power unit and field supply unit of Radiola 62. Disconnect the antenna and ground leads; the cable connecting the power units to the receiver and loudspeaker and the A.C. supply cord at its outlet.

A pair of headphones with at least $4\frac{1}{2}$ volts in series, or a voltmeter with sufficient voltage to give a full scale deflection when connected across the battery terminals should be used in making these tests. The receiver Radiotron sockets, numbers and lugs used in these tests are shown in Figure 18. The receiver continuity wiring diagram is illustrated in Figure 20. The S.P.U. and field supply unit terminal numbers are shown in Figures 19 and 21.




Figure 18—Radiotron socket contacts, location of parts, connection lugs and terminal strips of the socket power and field supply units




Figure 19—Continuity wiring diagram of the socket power unit

SOCKET POWER UNIT CONTINUITY TESTS		
Remove Radiotron UX-280 and Disconnect Cable at Terminal Strip		
<i>Terminals</i>	<i>Correct Effect</i>	<i>Incorrect Effect Caused by</i>
G to P of UX-280 socket	Closed	Open high voltage winding of power transformer
Across filament contacts of UX-280 socket	Closed	Open UX-280 filament winding of power transformer
One filament contact of UX-280 socket to No. 2	Closed	Open filter reactors
Terminal No. 2 to No. 3	Closed	Open resistance unit
Terminal No. 2 to No. 4	Closed	Open resistance unit
Terminal No. 2 to No. 5	Open	Shorted 1 mfd. condenser
Terminal No. 2 to No. 7	Open	Shorted 3½ mfd. condenser
Terminal No. 3 to No. 6	Closed	Open resistance unit
Terminal No. 4 to No. 5	Open	Shorted .5 mfd. condenser
Terminal No. 5 to No. 6	Open	Shorted .5 mfd. condenser
Terminal No. 5 to No. 7	Open	Shorted 4 mfd. Condenser
Terminal No. 8 to No. 9	Closed	Open UX-171A filament winding and resistance unit
Terminal No. 10 to No. 11	Closed	Open UY-227 filament winding and resistance unit.




Figure 20—Continuity wiring diagram of receiver

RECEIVER ASSEMBLY CONTINUITY TESTS

Remove all Radiotrons and Disconnect Cable at Terminal Strips
See Figure 18 for cable lugs, terminals, and Radiotron socket contacts

<i>Circuit</i>	<i>Terminals</i>	<i>Correct Effect</i>	<i>Incorrect Effect Caused by</i>
Grid	Antenna lead to ground lead	Closed	Open antenna resistor
	Antenna lead to G1	Closed	Open connection
	G2 to ground	Closed	Open secondary of 1st R.F. transformer
	G3 to Lug No. 5	Closed	Open secondary of 2nd R.F. transformer or resistance unit
	G4 to ground	Closed	Open secondary of 1st I.F. transformer
	G5 to ground	Closed	Open secondary of 2nd I.F. transformer
	G7 to ground	Closed	Open secondary of 3rd I.F. transformer or resistance unit
Plate	G8 to Lug No. 6	Closed	Open secondary of audio transformer or resistance unit
	Lug No. 5 to Lug No. 7 Ground to Lug No. 7	Closed Closed	Open resistance unit or volume control Open volume control contact arm or poor connection
Plate	P1 to Lug No. 3	Closed	Open primary 1st R.F. transformer
	P2 to Lug No. 3	Closed	Open primary 2nd R.F. transformer
	P3 to Lug No. 4	Closed	Open primary 1st I.F. transformer
	P4 to Lug No. 3	Closed	Open primary 2nd I.F. transformer
	P5 to Lug No. 3	Closed	Open primary 3rd I.F. transformer
	P6 to Lug. No. 4	Closed	Open plate coil of oscillator coils
	P7 to Lug No. 2	Closed	Open primary of audio transformer
	P8 to Lug No. 1	Closed	Open connection
Filament	Cathodes No. 1, No. 2, No. 4 and No. 5 to Lug No. 6	Closed	Open connection
	Cathodes No. 3, No. 6 and No. 7 to Lug No. 5	Closed	Open pick-up winding of oscillator or connection
	Lug No. 8 to one filament contact Socket No. 8	Closed	Open connection
	Lug No. 9 to other closed filament contact Socket No. 8	Closed	Open connection
	Lug No. 10 to one heater contact of Sockets Nos. 1, 2, 3, 4, 5, 6 and 7	Closed	Open connections
Miscellaneous	Lug No. 11 to other heater contact of Sockets Nos. 1, 2, 3, 4, 5, 6 and 7	Closed	Open connections
	G2 to P2	Open	Shorted compensating condenser
	G4 to P4	Open	Shorted neutralizing condenser
	G5 to P5	Open	Shorted neutralizing condenser
	G6 to Cathode 6	Closed	Open oscillator grid leak
	G8 to Lug No. 5	Closed (Weak)	Open resistance unit or secondary of A.F. transformer
	G8 to Lug No. 7	Closed	Open secondary of A.F. transformer or open volume control
Miscellaneous	Lug No. 12 to Lug No. 13	Closed	Open cone coil of reproducer unit
	Lug No. 14 to Lug No. 2	Closed	Open connection
	Lug No. 15 to Lug No. 5	Closed	Open connection




Figure 21—Continuity wiring diagram of field supply unit

FIELD SUPPLY UNIT CONTINUITY TESTS

Remove all Cable Connections

<i>Terminals</i>	<i>Correct Effect</i>	<i>Incorrect Effect Caused by</i>
3 to 4	Closed	Open secondary of output transformer
5 to 6	Closed	Open output choke
5 to 7	Open	Shorted output condenser

VOLTAGE READINGS AT FIELD SUPPLY UNIT

Connect all Cables and turn power "On"

<i>Terminals</i>	<i>Voltage</i>
1 to 2	100 D.C.
5 to 6	10 D.C.
5 to S.P.U. No. 7	200 D.C.
8 to 9	120 A.C.

[23] VOLTAGE READINGS AT RADIOTRON SOCKETS

The following voltages taken at each Radiotron Socket with the receiver in operating condition should prove of value when checking is done with test sets such as the Weston Model 537 Type 2 or others giving similar readings. The plate currents shown are not necessarily accurate for each tube, as the cable in the test set will cause some circuits to oscillate, due to its added capacity. Small variations of voltages will be caused by different tubes and line voltages. Therefore the following values must be taken as approximately those that will be found under varying conditions. These readings are equally applicable to Radiola 60. The numbers in column 1 indicate the tube socket numbers shown in Figure 18.

VOLUME CONTROL AT ZERO					
110-volt line. Switch at 110-volt position.					
<i>Tube No.</i>	<i>Cathode to heater. Volts</i>	<i>Cathode or filament to Grid. Volts</i>	<i>Cathode or filament to Plate. Volts</i>	<i>Plate Current Milliamps.</i>	<i>Filament or heater. Voltage</i>
1	30	30	165	—	2.5
2	30	30	165	—	2.5
3	—	11	90	.75	2.5
4	30	30	165	—	2.5
5	30	30	165	—	2.5
6	—	—	75	7.0	2.5
7	—	20	175	1.0	2.5
8	—	37	160	18.0	5.0

VOLUME CONTROL AT MAXIMUM					
110-volt line. Switch at 110-volt position.					
<i>Tube No.</i>	<i>Cathode to heater. Volts</i>	<i>Cathode or filament to Grid. Volts</i>	<i>Cathode or filament to Plate. Volts</i>	<i>Plate Current Milliamps.</i>	<i>Filament or heater. Voltage</i>
1	27	10	130	3.5	2.5
2	27	10	130	3.5	2.5
3	—	10	70	.5	2.5
4	25	10	130	9.0	2.5
5	25	10	130	9.0	2.5
6	—	—	65	7.5	2.5
7	—	20	165	.75	2.5
8	—	35	150	6.0	5.0

PART III—MAKING REPLACEMENTS

The various assemblies and parts of Radiola 62 are readily accessible and replacements can be easily made. Figure 22 illustrates the parts in the receiver assembly, Figure 2 in the S.P.U. and Figure 3 in the field supply unit. The following detailed procedure outlines the simplest method to be used in making replacements.

[1] REPLACING THE VOLUME CONTROL

- (a) Remove the knobs on the volume control and station selector. These are of the push type, and they are removed by simply pulling them off the shafts. Between each knob and the cabinet will be found a dilecto washer. These washers must also be removed. To replace, merely push the knob on to the shaft, first matching the knob socket with its flat spring to the shaft.




Figure 22—Receiver sub-Chassis showing principal parts

- (b) Open rear doors and release the pilot lamp and socket by pulling it from the small angle bracket to which it is clipped in place. A slight pull, upward and backward, will release it.
- (c) Remove the shield and insulating cover that are over the two terminal strips. Then remove all cable connections to each strip.
- (d) Release the two connections to the cone coil terminals from the cable. These are located on the loudspeaker flange.
- (e) Remove the clamps that hold the cable and antenna wire to the side of the cabinet.
- (f) Remove the antenna and ground wires from their binding posts.
- (g) Pull cable, antenna and ground leads through the hole in the shelf until all leads are clear.
- (h) Remove the four screws that hold the receiver assembly to the shelf.
- (i) The receiver assembly may now be lifted clear of the cabinet. (See Figure 23.) Place the volume control up and remove the two screws and nuts that hold it in place. The three soldered connections must also be removed.

- (j) Remove the old volume control and fasten the new one in position by means of the two machine screws and nuts, and resolder the three connections. The correct connections of these leads are shown in Figure 20.
- (k) Return receiver assembly in cabinet and replace all cables and leads in the reverse manner of that used to remove them.
- (l) Test Radiola and if O. K. return shield to its original position.

[2] REPLACING R. F. TRANSFORMER AND OSCILLATOR ASSEMBLY

The two radio frequency transformers and the oscillator coils are mounted on a metal strip, together with three small adjustable condensers and two fixed condensers.

This assembly must be replaced as a unit—the matching of the coils being an important point in the operation of the receiver. Use the following procedure:

- (a) Remove receiver chassis from cabinet as described in Part III, Section 1.
- (b) Turn chassis on side and unsolder all leads to the assembly being replaced.
- (c) Remove the five machine screws and lock washers that hold the metal supporting strip to the receiver frame.
- (d) The assembly may now be removed and the new assembly fastened in position with the five machine screws and washers previously removed.
- (e) Resolder all connections in their correct position on the assembly. This is shown in Figure 20.
- (f) The receiver assembly may now be returned to the cabinet in the reverse manner of that used to remove it.

[3] REPLACING RADIOTRON GANG SOCKETS

One socket assembly on the receiver chassis is of the gang variety, the others being two single units. All are held in place, together with their shields, by means of rivets which clamp them on the metal chassis frame. Use the following procedure when replacing these sockets:

- (a) Remove the receiver assembly from the cabinet as described in Part III, Section 1.
- (b) Unsolder all connections to the particular socket or assembly being removed. The R.F. transformer assembly should be removed as a unit to provide room for replacing the six-gang Radiotron socket.
- (c) Drill out the rivets holding the Radiotron socket to be replaced. The socket and shield will be released together, in the case of the single UY socket. In the case of the single UX or the gang UY the shield overlaps and will be held in place by the socket not removed.
- (d) Remove the old Radiotron socket and fasten the new one in position by means of screws, nuts and washers. Resolder all connections and replace the R.F. assembly if removed. The correct connections are shown in Figure 20.
- (e) Fasten receiver assembly in cabinet, connect cable and test. If O.K., replace shield over terminal strip and return Radiola to normal operation.

[4] REPLACING MAIN TUNING CONDENSERS AND DRIVE

The main tuning condensers and drive are replaced as one unit as follows:

- (a) Remove receiver assembly from cabinet as described in Part III, Section 1.
- (b) Remove the three screws, nuts and lock washers that hold the condenser assembly to the metal frame.
- (c) Now pull the condensers as far forward as possible and unsolder the four leads connected at the rear. Releasing the condensers and pulling them forward provides ample space in which to do the unsoldering job and keeps solder material clear of the tube shield. Remove the entire assembly by tilting slightly and pulling clear.
- (d) Place the new assembly in the position occupied by the old one and solder the four leads to their proper connections.

- (e) Fasten the three screws, nuts and lock washers in their proper position. Make sure that the screw that holds the ground connection on the under side of the chassis makes firm contact.
- (f) Return the receiver to the cabinet and replace all connections in the reverse order of that used to remove them.

[5] REPLACING BY-PASS CONDENSERS

Radiola 62 employs two by-pass condensers in the receiver assembly. They are both located on the under side of this assembly, and replacement is made in the following manner:

- (a) Remove receiver assembly as described in Part III, Section 1.
- (b) Unsolder the connections to the condenser it is desired to replace.
- (c) With a screwdriver bend up the metal tabs holding the condenser to the side of the receiver frame. These tabs bend easily, and when turned up make possible the removal of the condenser.




Figure 23—Removing receiver chassis from cabinet

- (d) The new condenser should now be fastened in place in the position formerly occupied by the old one.
- (e) Resolder the connections as shown in Figure 20.
- (f) Fasten the receiver assembly in the cabinet in the reverse order of that used to remove it.

[6] REPLACING THE AUDIO TRANSFORMER

Radiola 62 employs one audio transformer, located at the left side of the receiver assembly facing the front of the Radiola. Should a replacement become necessary use the following procedure:

- (a) Remove receiver assembly as described in Part III, Section 1.
- (b) Place the receiver chassis on its side and unsolder all connections to the audio transformer.
- (c) Now turn up the four tabs that hold the transformer in place and remove it. The new one is then fastened in position.
- (d) Resolder the leads from the new transformer to their correct points of connection as indicated in Figure 20.
- (e) Fasten the receiver assembly in the cabinet in the reverse order of that used to remove it.

[7] REPLACING CONDENSER DRIVE CABLE

- (a) Remove receiver assembly from cabinet as described in Part III, Section 1. Place chassis on a table so that the cable on the grooved drums is accessible.
- (b) Release the cable adjusting screw and clamp, and remove old cable from drums completely.
- (c) Starting from the rear grooved drum, place eye of new cable over pin, which should be in a horizontal position and next to side of the assembly that is closest to the Socket Power Unit when in the cabinet, and wind on three complete turns and then bring cable up to large drum.
- (d) Now pass cable over large drum. Turn the drum so the cable adjusting screw is on top. Pass cable over groove until point is reached where there is a slot in the drum for passing the cable to the track on the other side of the drum.
- (e) Follow on around other track in same direction until a point is reached where cable is directly above front grooved drum.
- (f) Starting on the third groove back from the front of the drum, wind on two and a half turns and slip eye over pin. The cable is now in its correct position, although probably slack.
- (g) The cable adjusting screw and clamp that were previously removed to allow the cable to pass along the grooves are replaced. By slipping the clamp over the cable and gradually turning up on the cable adjusting screw, the cable may be tightened until there is no lost motion in any of its controls. Care should be taken not to take up too much, as the cable may be stretched or possibly broken.
- (h) Return receiver assembly to cabinet in the reverse order of that used to remove it

[8] REPLACING DIAL SCALES

After considerable use a dial scale may become soiled or illegible and a new scale desired. A step-by-step procedure to make replacement follows:

- (a) Open rear door of Radiola 62.
- (b) Turn dial so that the two screws that hold the dial in place are toward the rear.
- (c) Loosen screws, washers and nuts that hold dial in place.
- (d) The old dial may now be pulled clear and the new one placed in the position occupied by the old one. Examine dial from the front of the Radiola to see that the numbers on the dial are in their correct position.
- (e) Tighten screws holding dial in place and close doors of cabinet.

[9] REPLACING POWER CABLE

A combination laced and braided cable is used in Radiola 62 for connecting the S.P.U. and field supply unit to the receiver assembly and the reproducer unit. Should it be necessary to replace this cable use the following procedure:

- (a) Remove receiver assembly from cabinet as described in Part III, Section 1.
- (b) Turn assembly bottom side up and unsolder all connections to the cable.
- (c) Remove old cable and connect up the new cable as indicated in Figure 20, soldering all connections.
- (d) Return assembly to cabinet in reverse order of that used to remove it.

[10] REPLACING INTERMEDIATE TRANSFORMERS

Radiola 62 has three intermediate frequency transformers, all three being exactly the same mechanically, and interchangeable electrically after the correct adjustments have been made for their particular position in the circuit. A step-by-step replacement procedure follows:

- (a) Remove receiver assembly from cabinet as described in Part III, Section 1.
- (b) Remove tuning condenser assembly as described in Part III, Section 4.
- (c) Unsolder the connections of the transformer being replaced. Then turn up the metal tabs on the upper side of the receiver chassis. The old transformer may now be replaced by the new one. Turn over the metal tabs to hold it in place and resolder all connections. These are shown in Figure 20. Be careful not to heat any connection more than necessary to make a good joint, as excessive heat may change the capacity of the primary fixed condenser, thus rendering the entire transformer assembly defective.
- (d) Before returning the main tuning condensers to the receiver chassis it will be necessary to tune and neutralize the transformer just connected in position. The correct procedure for doing this is contained in Part II, Section 14.
- (e) The procedure given in Part II, Section 14 may now be carried out. Then return the tuning condenser assembly in the reverse order of that used to remove it. The entire receiver may now be tested and a check made on the adjustment of the oscillator trimming condensers as described in Part II, Section 12. After all tests and adjustments are completed the receiver assembly should be returned to the cabinet in the reverse order of that used to remove it.

[11] REPLACING TAPPED RESISTANCE UNIT IN RECEIVER ASSEMBLY

A tapped resistance unit in the receiver assembly of Radiola 62 provides the various grid and cathode voltages. To replace this tapped resistance unit proceed as follows:

- (a) Remove receiver assembly as described in Part III, Section 1.
- (b) Unsolder all connections to the tapped resistance unit.
- (c) Remove the two screws, nuts and washers that hold the resistance unit in place. This will release the unit and the new one can be fastened in place with the screws, nuts and washers previously removed.
- (d) Solder all the leads to their correct connections. (See Figure 20.)
- (e) Return receiver assembly to cabinet in the reverse order used to remove it.

[12] REPLACING CONE OF REPRODUCER UNIT

Should it be desirable to replace a cone, the entire reproducer unit must be removed from the cabinet. In order to do this use the following procedure:

- (a) Remove the cover over the terminal strip and remove the field supply leads from terminals 1 and 2 of the field supply unit.
- (b) Remove the two cone coil leads and the connections from the power cable that are connected to the terminals on the flange of the reproducer unit.
- (c) Remove the four nuts that hold the reproducer to the baffle board, at the same time supporting the reproducer by hand to prevent it falling on the S.P.U. Place the unit in some position convenient for work.
- (d) Remove the nine nuts and machine screws that hold the cone ring in place. Remove this ring.
- (e) Remove the screw and washer that centers the cone. The cone may now be removed and the new one placed in the position occupied by the old one.
- (f) Return the centering screw; the ring and its nine screws and nuts to position, but do not tighten. The cone should now be centered as described in Part II, Section 21 and all screws tightened.
- (g) The unit should now be returned to the cabinet in the reverse manner of that used to remove it.

[13] REPLACING FILTER CONDENSERS AND BY-PASS CONDENSERS

The filter condensers and by-pass condensers are enclosed as a unit in a metal container. Should replacement be necessary, use the following procedure:

- (a) Remove the shield and all connections from the Socket Power Unit terminal strip.
- (b) Remove the four machine screws that hold the S.P.U. to the cabinet. The S.P.U. may now be lifted clear of the cabinet.
- (c) Unsolder all connections to the unit being replaced, also release the two resistors attached to its connecting terminal.
- (d) Bend up the tabs that hold the unit to the S.P.U. base. Remove the old unit and fasten the new one in position by bending the tabs down so that it is held tightly to the S.P.U. base.
- (e) Replace and solder all connections and the resistance units previously removed. Their correct connections are shown in Figure 19.
- (f) Return the S.P.U. to the cabinet in the reverse order of that used to remove it. Replace all connections and test. If O.K., replace shield over terminal strip and return Radiola to normal operation.

[14] REPLACING POWER TRANSFORMER OR FILTER REACTOR

The power transformer and filter reactor are both held in place by means of tabs which form a part of their case, being turned over on the under side of the S.P.U. base. A step-by-step replacement procedure follows:

- (a) Remove S.P.U. from cabinet as described in Part III, Section 13.
- (b) Unsolder all connections to unit being replaced. If the power transformer is being replaced release the two screws that hold the center tapped resistance units in place, so they may be pulled clear when bending the tabs on the power transformer.

- (c) Bend up the tabs that hold the unit to the S.P.U. base.
- (d) The old unit may now be removed and the new one placed in position. Bend over the tabs on the new one so that it is fastened tightly to the S.P.U. base.
- (e) Solder all connections as shown in Figure 19.
- (f) Fasten the S.P.U. in the cabinet in the reverse order of that used to remove it.

[15] REPLACING TERMINAL STRIP

Should the terminal strip on the S.P.U. require replacement use the following procedure:

- (a) Remove the S.P.U. from cabinet as described in Part III, Section 13.
- (b) Unsolder all leads to the terminal strip.
- (c) Release two screws holding strip to S.P.U. base.
- (d) The strip may now be removed and replaced by a new one.




Figure 24—Removing the field supply unit from the cabinet

- (e) Fasten new strip in position by means of two machine screws, lock washers and nuts previously removed.
- (f) Solder all leads to terminal strip. The color scheme and correct connections are shown in Figure 19.
- (g) Return S.P.U. to cabinet in the reverse order, and connect to receiver assembly.

[16] REPLACING MISCELLANEOUS PARTS IN S. P. U.

The center tapped resistors, plate supply resistors, line switch and UX-280 socket in Radiola 62 may require replacement. They are all attached to the base by means of machine screws and nuts, and replacement is very simple. The following general outline will apply to all these units:

- (a) Remove S.P.U. from cabinet as described in Part III, Section 13.
- (b) Unsolder leads from defective unit.
- (c) Remove defective unit from base and replace with new unit.
- (d) Solder leads to new unit as indicated in Figure 19.
- (e) Return S.P.U. to cabinet in reverse order of that used to remove it.

[17] REPLACING COUPLING UNIT

A choke and condenser together with a step-down transformer are used to couple the output of the Radiotron UX-171A to the cone coil of the reproducer unit. Should replacement become necessary, proceed as follows:

- (a) Remove the shield and insulating strip over the field supply terminal strip.
- (b) Remove all connections to this strip and then remove the four machine screws used to hold the unit in place.
- (c) Remove the field supply unit to a place convenient for work. See Figure 24.
- (d) Unsolder all connections to the coupling unit being replaced. Turn up the tabs holding it in place and remove the defective unit from base.
- (e) The new unit should now be placed in the position occupied by the old one and fastened in place by bending its tabs. All connections should be soldered in place as shown in Figure 21.
- (f) The field supply unit is then returned to the cabinet in the reverse manner of that used to remove it and the Radiola returned to normal operation.

[18] REPLACING CONDENSER BANK OF FIELD SUPPLY UNIT

Across the output of the disc rectifier there is a 4 mfd. condenser. Also across the input A.C. supply are two .1 mfd. condensers connected in series with the mid-point grounded. These condensers are contained in one unit and are replaced as follows:

- (a) Remove field supply unit from cabinet as described in Part III, Section 17.
- (b) Unsolder the connections to the condenser bank being replaced. Turn up the tabs that hold it in place and remove from field supply unit base.
- (c) Place the new unit in the place occupied by the old one and turn tabs to hold unit in place.
- (d) Resolder all connections in their correct positions. These are shown in Figure 21.
- (e) The unit is then returned to the cabinet in the reverse order of that used to remove it.

[19] REPLACING RECTIFIER STACK

The disc rectifier used in Radiola 62 is made in two units, either of which may be replaced independently of the other. The replacement procedure follows:

- (a) Remove the field supply unit from the cabinet as described in Part III, Section 17.
- (b) Remove the protective screen over the rectifier unit by bending up the tabs that hold it in place.
- (c) Unsolder all connections to the defective unit.
- (d) Release the unit by removing the bolts and nuts that hold it in place. Place the new unit in the position occupied by the old one and fasten in place.
- (e) Resolder all connections removed. These are shown in Figure 21.
- (f) Return shield to its correct position and fasten in place by turning down its tabs.
- (g) Return field supply unit to cabinet in reverse manner of that used to remove it and return Radiola to normal operation.

SERVICE DATA CHART

Before using the following Service Data Chart, when experiencing no signals, weak signals, poor quality, noisy or intermittent reception, howling and fading, first look for defective tubes, or a poor antenna system. If imperfect operation is not due to these causes the "Service Data Chart" should be consulted for further detailed causes. Reference to Part No. and Section No. in the "Service Notes" is also noted for further details.

<i>Indication</i>	<i>Cause</i>	<i>Remedy</i>
No signals	Defective operating switch Loose volume control arm Defective power cable Defective R.F. transformer Defective I.F. transformer Defective A.F. transformer Defective Oscillator coil Defective by-pass condenser Defective socket power unit Defective Field Supply Unit Open cone coil of reproducer unit	Repair or replace switch Tighten volume control arm, P. II, S. 4 Replace power cable, P. III, S. 9 Replace R.F. and oscillator coil assembly, P. III, S. 2 Replace I.F. transformer, P. III, S. 10 Replace A.F. transformer, P. III, S. 6 Replace R.F. and oscillator coil assembly, P. III, S. 2 Replace by-pass condenser, P. III, S. 5 Check socket power unit by means of continuity test, and make any repairs or replacements necessary, P. II, S. 22 Check field supply unit and make any repairs or replacements necessary Check cone coil and if open replace cone
Weak Signals	Compensating condenser out of adjustment Trimming condensers out of adjustment I.F. transformers not correctly aligned Defective power cable Defective R.F. transformer Defective I.F. transformer Defective A.F. transformer Dirty prongs of Radiotrons Defective by-pass condenser Defective main tuning condenser Low voltages from socket power unit Defective socket power unit	Adjust compensating condenser correctly, P. II, S. 13 Adjust trimming condensers, P. II, S. 12 Align I.F. transformers correctly, P. II, S. 14 Repair or replace cable, P. III, S. 9 Replace R.F. and oscillator coil assembly, P. III, S. 2 Replace I. F. transformer, P. III, S. 10 Replace A. F. transformer, P. III, S. 6 Clean prongs with fine sandpaper, P. II, S. 3 Replace defective by-pass condensers, P. III, S. 5 Replace defective tuning condensers, P. III, S. 4 Check socket power unit voltages with high resistance D.C. voltmeter and A.C. voltmeter, P. II, S. 17 Check socket power unit by means of continuity tests and make any repairs or replacements necessary, P. II, S. 22
Poor Quality	Defective A.F. transformer Defective by-pass condenser Dirty contact arm of volume control Dirty prongs on Radiotrons Volume control advanced too far	Replace A.F. transformer, P. III, S. 6 Replace defective by-pass condenser, P. III, S. 5 Clean contact arm on volume control, P. II, S. 4 Clean prongs with fine sandpaper, P. II, S. 3 Reduce setting of volume control, P. I, S. 7
Howling	Compensating condenser out of adjustment Defect in audio system Open grid circuit in any stage Microphonic Radiotrons	Adjust compensating condenser correctly, P. II, S. 13 Check and repair any defect, P. II, S. 10 Check circuit and repair defect Interchange Radiotrons
Excessive Hum	Defective center tapped resistance unit Socket plug position Line voltage low Antenna and ground leads reversed	Replace defective resistance unit, P. III, S. 16 Reverse socket plug Set line switch for low line voltage, P. I, S. 5 Connect antenna and ground leads correctly
Radiotrons Fail to Light	Operating switch not "On" Defective operating switch Defective input A.C. cord Defective power transformer No. A.C. line voltage	Turn operating switch "On" Replace operating switch Repair or replace A.C. input cord Replace power transformer, P. III, S. 14 Turn A.C. line voltage "On"