


# All RCA Victor Service Notes ... Now in Five Bound Volumes



*This library contains complete service information, drawings and price lists 1923-1934*

So immediate was the acceptance of the bound volumes of RCA Victor Service Notes for 1931-32 and 1933; so strong was the demand that three more volumes have been compiled. There are now five bound volumes included in the RCA Victor Service Library.

The five volumes cover all RCA or Victor models produced from 1923 to 1935 except old Victrola instruments that did *not* contain a radio receiver. Complete replacement parts lists are provided for all models issued since 1929.

When the Service Engineer wants technical information on any RCA Victor model, he turns to the index of his bound volume; a moment later diagrams, parts lists and prices and service notes are lying *flat* on the table before him.

Service Engineers who use the volumes regard them as their "Business Bible," not alone for the diagrams and drawings but for the time saving service information, conveniently arranged for every RCA Victor receiver. Schematic drawings can be obtained elsewhere, but the technical information is not so readily found.

In addition, each volume will contain other valuable information such as impedance, inductance and capacity charts, and other data peculiar to the receivers described therein.

A limited edition is being published and to make sure of copies for yourself, we suggest that you place your order now.

★ NET PRICE ★  
**\$1<sup>00</sup> PER VOLUME**

F. O. B. CAMDEN, N. J.

---

---

ORDER FROM YOUR RCA PARTS DISTRIBUTOR

# CONTENTS

1923-28

<p><b>INSTRUCTIONS AND CIRCUIT DIAGRAMS</b></p> <p>RCA Radiola AR (Radio Frequency Amplifier)</p> <p>RCA Radiola RT (Antenna Coupler)</p> <p>RCA Radiola RC Schematic Diagram and Battery Connections</p> <p>RCA Aeriola, Sr., Schematic Diagram</p> <p>RCA Radiola RS (Regenerative Receiver and Amplifier)</p> <p>RCA Radiola AC (2-Stage Audio Amplifier)</p> <p>RCA Radiola, Sr., and Type AC Amplifier Schematic Diagram and Battery Connections</p> <p>RCA Radiola RS and Balanced Amplifier Schematic Diagram and Battery Connections</p> <p>Model AR-1300 Radio Receiver</p> <p>Model AA-1400 Detector Amplifier</p>	<p>Model AA-1520 Radio Frequency Amplifier</p> <p>RCA Radiola II</p> <p>RCA Radiola III</p> <p>RCA Radiola III-A</p> <p>RCA Radiola Balanced Amplifier</p> <p>Radiolas III, III-A and Balanced Amplifier Using Radiotrons UX-199 and UX-120</p> <p>RCA Radiola IV</p> <p>RCA Radiola V</p> <p>RCA Radiola VI</p> <p>RCA Radiola VII</p> <p>RCA Radiola VII-B</p> <p>RCA Radiola Super-VIII</p> <p>Use of UR-556 Adaptor</p> <p>RCA Radiola IX</p> <p>RCA Radiola X</p> <p>RCA Radiola Regenflex</p> <p>RCA Radiola Grand</p> <p><b>BATTERY CONNECTIONS</b></p> <p>RCA Radiola Super-Heterodyne (Semi-Portable) Battery Connections</p>	<p>RCA Radiola 20 Battery Connections</p> <p>RCA Radiola 24 Battery Connections</p> <p>RCA Radiola 25 Battery Connections</p> <p>RCA Radiola 26 Battery Connections</p> <p>RCA Radiola 28 Battery Connections</p> <p><b>RCA RADIOLA AND LOUDSPEAKER SERVICE NOTES</b></p> <p>RCA Radiola 16</p> <p>RCA Radiola 17</p> <p>RCA Radiola 18</p> <p>RCA Radiolas 18 D. C. and 51 D. C.</p> <p>RCA Radiola 20</p> <p>RCA Radiola 25</p> <p>RCA Radiolas 25 and 28 A. C.</p> <p>RCA Radiolas 26, 24 Super-Heterodyne and Super VIII</p> <p>RCA Radiola 28</p> <p>RCA Radiola 30</p>	<p>RCA Radiola 30-A</p> <p>RCA Radiolas 30-A D. C., 32 D. C. and 104 D. C.</p> <p>RCA Radiola 32</p> <p>RCA Radiola 41</p> <p>RCA Radiola 41 D. C.</p> <p>RCA Loudspeaker 100</p> <p>RCA Loudspeaker 100-A</p> <p>RCA Loudspeaker 103</p> <p>RCA Loudspeaker 104</p> <p>RCA Loudspeaker 105</p> <p>RCA Loudspeaker 106</p> <p>RCA Power Amplifier AP-935</p> <p>RCA "B" Battery Eliminator AP-937</p> <p>Use of "B" Eliminator with Super VIII</p> <p>RCA "B" Eliminator AP-1080</p> <p>RCA Short-Wave Receiver AR-1145</p> <p><b>VICTOR RADIO RECEIVER AND ELECTROLA SERVICE NOTES</b></p> <p>Victor Model 7-1 (Alhambra I)</p>	<p>Victor Model 7-2 (Alhambra II) and 9-1 (Florenza)</p> <p>Victor Model 7-3 and 7-30</p> <p>Victor Model 7-10</p> <p>Victor Model 7-11 and 7-26</p> <p>Victor Model VE-8-60</p> <p>Victor Model 9-2 (Borgia II)</p> <p>Victor Model 9-3 (Borgia I)</p> <p>Victor Model 9-15</p> <p>Victor Model 9-16</p> <p>Victor Model 9-18</p> <p>Victor Model 9-25</p> <p>Victor Model 9-40 (Borgia)</p> <p>Victor Models 9-54 and 9-56</p> <p>Victor Model 9-55</p> <p>Victor Model 10-51</p> <p>Victor Model 10-69</p> <p>Victor Model 10-70</p> <p>Victor Model 12-1 (Cromwell)</p> <p>Victor Model 12-2 (Tuscany)</p> <p>Victor Model 12-15</p> <p>Victor Model 12-25</p> <p>Victor Model 15-1 (Hyperion)</p> <p>Victor Model 10-35</p> <p>Victor Model E-35</p>
--	--	--	--	---

1929-30

<p><b>RCA RADIOLAS AND LOUDSPEAKERS</b></p> <p>RCA Radiolas 21 and 22</p> <p>RCA Radiola 33</p> <p>RCA Radiola 33 D. C. (110 Volt)</p> <p>RCA Radiola 33 D. C. (220 Volt)</p>	<p>RCA Radiola 42 (also Victor Radio R-14)</p> <p>RCA Radiolas 44 and 46</p> <p>RCA Radiola 46 D. C. (110 Volt)</p> <p>RCA Radiola 47</p> <p>RCA Radiola 48 (also Victor Radio R-15)</p>	<p>RCA Radiola 60</p> <p>RCA Radiola 62</p> <p>RCA Radiola 64</p> <p>RCA Radiola 66</p> <p>RCA Radiola 67</p> <p>RCA Radiolas 80 and 82</p> <p>RCA Radiola 86</p>	<p>RCA Radiolas 82 and 86 (Remote Control)</p> <p>RCA Radiola Short-Wave Adaptor</p> <p>RCA Theremin</p> <p>RCA Loudspeaker 100-B</p> <p>RCA Power Amplifier AZ-774-B</p>	<p>RCA Magnetic Pickup AZ-1604</p> <p><b>VICTOR RECEIVERS</b></p> <p>Models R-32, RE-45, R-52 and RE-75</p> <p>Models R-35, R-39, RE-57</p> <p>Model RE-17</p>
---	--	---	---	--

1931-32

<p>RCA World-Wide Antenna System</p> <p>RCA Victor Shield Kits</p> <p>Frequency, Impedance, Inductance and Capacity Chart</p> <p>RCA Full-Range Test Oscillator</p> <p>RCA Tools and Accessories</p> <p>Radiotron Data Sheets</p> <p>SR-1, SR-2, and SR-3 (Two-Speed Turntables)</p>	<p>MB-1, MB-2, and MB-3 (Replacement Motor Boards)</p> <p>2-25</p> <p>2-65</p> <p>SWA-2</p> <p>R-4 and R-6</p> <p>R-5</p> <p>R-5X</p> <p>R-5 D. C.</p> <p>T-5</p> <p>R-7 (Superette)</p>	<p>R-7A</p> <p>R-7 L. W.</p> <p>R-7 D. C. and R-9 D. C.</p> <p>SK-7</p> <p>R-8 and R-12</p> <p>R-8 D. C. (220-volt)</p> <p>R-10</p> <p>R-10 D. C.</p> <p>R-11</p> <p>R-11 Supplement</p> <p>RE-16</p> <p>RE-16A</p>	<p>RE-18</p> <p>RE-18A</p> <p>RE-19</p> <p>RE-20</p> <p>R-21</p> <p>RO-23</p> <p>RAE-26</p> <p>CE-29</p> <p>M-30</p> <p>P-31</p> <p>M-32</p>	<p>PT-33</p> <p>R-43</p> <p>R-50 and R-55</p> <p>RAE-59</p> <p>RAE-68</p> <p>R-70</p> <p>RE-73</p> <p>R-74, R-76, and R-77</p> <p>RAE-79</p> <p>Automatic Record Changing Mechanism</p> <p>Special Service Information</p>
--	--	---	--	--

1933

<p>All Wave Reception Reception Chart</p> <p>Antenna Length Chart</p> <p>Predicting Reception</p> <p>Magnetic Activity Chart</p> <p>RCA World Wide Antenna System</p> <p>RCA Victor Shield Kits</p> <p>Frequency, Impedance, Inductance and Capacity Chart</p> <p>RCA Test Oscillator</p> <p>RCA Tools</p> <p>Replacement Vibrator</p> <p>Dealers Kits</p>	<p>Radiotron Data Station List</p> <p>R-3B</p> <p>R-3C</p> <p>SW-3</p> <p>CRD-9 D.C.</p> <p>CRD-9 A.C.</p> <p>R-17-M</p> <p>R-18-W</p> <p>R-22</p> <p>R-25 D.C.</p> <p>R-27</p> <p>R-27 (Revised)</p> <p>R-28</p>	<p>R-28 BW</p> <p>R-28 BWC</p> <p>R-28-P</p> <p>M-34</p> <p>R-37 and R-38</p> <p>R-37-P and R-38-P</p> <p>RE-40</p> <p>RE-40-P</p> <p>R-51-B and R-53-B</p> <p>R-71 and R-72</p> <p>R-71-B</p> <p>R-73</p> <p>R-73 (Revised)</p> <p>R-75</p>	<p>R-75 (Revised)</p> <p>R-78</p> <p>RE-80</p> <p>RE-81</p> <p>RAE-84</p> <p>R-90</p> <p>R-90-P</p> <p>TMV-97-A</p> <p>100 and 101</p> <p>100 and 101 (Revised)</p> <p>110, 111 and 115</p> <p>112</p> <p>114</p> <p>120</p>	<p>121 and 122</p> <p>140, 141, 141-E, 240 and AVR-1</p> <p>140 Volume Control Replacement</p> <p>142-B and 241-B</p> <p>220 and 222</p> <p>260</p> <p>280</p> <p>300</p> <p>310</p> <p>330</p> <p>331</p>
--	---	--	--	--

1934

<p>RCA Laboratory Equipment</p> <p>RCA Standard Signal Generator Type TMV-18-D</p> <p>RCA Universal Curve Recorder Type TMV-36-B</p> <p>RCA Beat Frequency Oscillator Type TMV-52-E</p> <p>RCA Field Intensity Meter Type TMV-75-B</p> <p>RCA Regulated S.P.U. Type TMV-118-B</p> <p>RCA Tools and Accessories</p> <p>RCA Full Range Test Oscillator Type TMV-97-B</p> <p>RCA Output Indicator Type TMV-121-A</p>	<p>RCA Auto Radio Accessories</p> <p>RCA Replacement Transformers</p> <p>RCA Pickup Kits</p> <p>RCA Phonograph Oscillator</p> <p>RCA Victor Bound Volume Service Notes</p> <p>RCA Cabinet Refinishing Kit</p> <p>RCA Radiotron Data Sheets</p> <p>RCA Victor Model R-91-B</p> <p>RCA Victor Model R-92</p> <p>RCA Victor Model R-93</p> <p>RCA Victor Model 102</p> <p>RCA Victor Model M-105</p>	<p>RCA Victor Model M-107</p> <p>RCA Victor Model 112-A</p> <p>RCA Victor Model M-116</p> <p>RCA Victor Models 118 and 211</p> <p>RCA Victor Model M-123</p> <p>RCA Victor Model 124</p> <p>RCA Victor Model 126-B</p> <p>RCA Victor Model 127</p> <p>RCA Victor Models 128 and 224</p> <p>RCA Victor Models 135-B and 235-B</p> <p>RCA Victor Models 143 and 242</p>	<p>RCA Victor Models 140, 141, 141-E and 240 (with external I. F. transformers)</p> <p>RCA Victor Model 221</p> <p>RCA Victor Model 223</p> <p>RCA Victor Model 261</p> <p>RCA Victor Model 262</p> <p>RCA Victor Model 281</p> <p>RCA Victor Model 301</p> <p>RCA Victor Model 320</p> <p>RCA Victor Model 321</p> <p>RCA Victor Model 322</p> <p>RCA Victor Model 327</p>	<p>RCA Victor Models 340 and 340-E (with external I. F. transformers)</p> <p>RCA Victor Model 341</p> <p>RCA Victor Model 380</p> <p>RCA Victor Model 380-HR</p> <p>RCA Victor Model 381</p> <p>Nine-Tube General Purpose All-Wave Receiver (AVR-5A)</p> <p>RCA Full Range Test Oscillator Type TMV-97-B Instructions</p> <p>RCA World Wide Antenna Installation Instructions</p>
---	---	---	---	---